Disassembling IBM ThinkPad A30 Battery

This dissassembly guide shows how to remove the ThinkPad A30 battery.


Written By: Alan



INTRODUCTION

This guide will show you how to remove the battery for the ThinkPad A30.

Step 1 — Battery





- Flip the ThinkPad over so that it is upside down.
- Slide the highlighted tab to the left.
- With your finger on the tab, remove the battery by lifting it upwards away from the laptop.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-25 08:04:01 AM.